

## Mounting the aluminum blocks onto your trimmer shaft

The locking end aluminum block should be mounted on the engine end of the line trimmer about 1/4" in front of the throttle assembly.

The support end aluminum block should be mounted towards the cutting head of the line trimmer, it can be mounted with the spike facing toward the engine or toward the cutting head.

- 1) Bolt the aluminum blocks onto your trimmer shaft, leave the support side loose but tighten the locking side.
- 2) Secure the line trimmer into the locking side rack, then slide the support side aluminum block into the funnel shaped receiver and tighten it in place.

